

**Work Order ID 59711**

Wednesday, June 09, 2010 3:40:29 PM

Page 1

Item ID: D3537-3

Accept

Setup Start

Revision ID:

Stop

Item Name: Wearpad

Start Date: 6/9/2010 Start Qty: 16.00

Required Date: 6/16/2010 Req'd Qty: 16.00

Cust Item ID:

Customer:

Reference: Return 2010 RA110039

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run Start

QC:

Date: 10-06-09

SPC (Y/N):

Date:

Stop

Sequence ID/  
Work Center IDOperation  
DescriptionSet Up/  
Run Hours

Tool ID

Tool # Plan  
CodeAccept  
QtyReject  
QtyReject  
NumberInsp.  
Stamp

Draw Nbr

Revision Nbr

D3537

Rev C

100

QC5- Inspect part completeness to step on W/O

0.00



QC

Quality Control

Memo

Original B35697

Parts in good condition

0.00

S 6/06/09

+16

110

Identify as per dwg &amp; Stock Location

0.00



Packaging

Packaging

Memo

Identify with the new batch #

0.00

10-6-16 SP

120

QC21- Final Inspection - Work Order Release

0.00



QC

Quality Control

Memo

0.00

10/06/14

MF

10-6-14